






IDENTIFICATION OF THE PARTS: FOR OLYMPUS EM-5 MARK III HOUSING




1. Locking knob
2. Hole M8
3. Fiber optic connection
4. Lens release button
5. ON/OFF lever
6.  LV button
7.  (sequential shooting/self-timer) button
8. Hole M16x1
9. Port safety lever



EN



10. Mode dial lock button
11. REC - Movie button
12.  Exposure compensation button
13. Shutter lever
14. Front dial
15. Preview button

16. Viewfinder
17. Humidity sensor led
18. Mode dial
19. ISO button
20. Rear dial
21. Fn lever
22. INFO button
23.  Playback button
24. Arrow pad and OK button
25.  Erase button
26. MENU button
27. AEL/AFL/ button

