








IDENTIFICATION OF THE PARTS: FOR OMSYSTEM OM-1 HOUSING





1. Locking knob
2. Hole M28x1
3. Fiber optic connection
4. Hole M16x1
5. ZOOM gear
6. Lens release button
7. Port safety lever
8. ON/OFF lever
9. AF/  button
10.  /  /  button



EN



11.  button
12. Mode dial lock button
13. AF-ON lever
14. REC - Movie lever
15. Shutter lever
16. Front dial
17. One-touch white balance lever

18. Viewfinder
19. ON/OFF  lever
20.  button
21. MENU button
22. Vacuum sensor led (if in use)
23. Humidity sensor led
24. Mode dial
25. Rear dial
26. Fn lever
27. ISO button
28. Arrow pad and OK button
29. INFO button
30.  button
31.  button
32. Multi selector button
33. AEL button

