



IDENTIFICATION OF THE PARTS: FOR ALPHA 7S III HOUSING



1. Locking knob
2. Fiber optic connection
3. Hole M8
4. Hole M16x1
5. Zoom gear
6. Port safety lever
7. Hole M24x1



EN



8. Mode dial
9. Exposure compensation dial lock button
10. C1 lever
11. C2 button
12. AF-ON lever
13. REC - MOVIE lever
14. ON/OFF switch
15. Shutter lever
16. Front dial
17. Lens release lever

18. C3 button
19. Menu button
20. Viewfinder
21. Humidity sensor led
22. Exposure compensation dial
23. Rear dial
24. AEL button
25.  button
26. Multi-selector buttons
27. C4/  button
28. Control wheel buttons
29. Fn button

